

COVING

Fixing Instructions

All surfaces should be clean and dry. We recommend sanding any previously painted area to improve adhesion.

Measures and cut the coving using a conventional hand saw. For coving it is best to mark out the wall before commencing installation, the use of small masonry pins nailed along the horizontal pencil lines at suitable centres will hold the coving in position whilst the adhesive is setting.

After cutting check the dimensions by offering up the cut piece to the fixing position.

Apply the adhesive and install the coving, any surplus adhesive should be cleaned off with a damp cloth. Any uneven surfaces can then be filled.