

NUTRIM

Fixing Instructions

Method of Fixing for Built up Felt Roofing

Nutrim should be fixed by means of Cadmium or Galvanised nails or screws at not more than 300mm centres, with the ends of each length firmly secured. A minimum of 8 fixings per length is recommended.

Priming of the fixing leg is recommended.

The first layer of felt should be dressed over the kerb and the Nutrim fixed into position as described. The top layer of felt is laid in a similar manner over the trim and the top edge turned into the hood, thus eliminating the outside edge of the top layer of felt lifting.

