

DECORATIVE CLADDING

Fixing Instructions

Decorative cladding panels are easy to install. Provided the wall surface is completely flat panels can be glued to the wall. If not they can be either nailed screwed or stapled to wooden battens. In rooms with a high humidity treated wood and stainless steel fixings should be used.

If wooden battens are used they should be fixed at approx. every 30-cm. To install the panels vertically, place the battens horizontally and vice versa.

Continue by measuring the number of panels you will need for the wall. If the last Panel is too narrow, we advise to saw the first panel so that you have at least 4 cm on either side.

If multipurpose trims are to be used at the top or bottom of the walls they may require fixing before the panels are installed.

Install the first panel making sure that it is placed perfectly vertical before fixing it to the wall. (We recommend using a spirit level or weighted thread). Panels are easy to fix by stapling, nailing or screwing through the lip of the panel onto the batten. (Every 30cm). A fine tooth saw is recommended for cutting the panels.

To continue installation, insert the second panel into the designated groove of the first panel checking the vertical position and then fix. Continue this procedure until the whole surface is covered. A multipurpose trim can be used for internal and external corners or alternatively these can be formed by a small incision to the back of the panel and bending the panel around the corner.

Maintenance

Use normal cleaning products and a soft cloth or sponge. Never use abrasive or aggressive products for cleaning the panels.