

# V-TRIM

## Fixing Instructions

V- Trim should be fixed with screws at not more than 300mm centres, with the ends of each length firmly secured. A minimum of 8 fixings per length is recommended.

V- Trim can be fixed in position prior to the laying of the asphalt. On timber kerbs, the sheathing felt and expanded metal lathing should be fixed to the inside edge of the fixing arm. On concrete roofs the sheathing felt is stopped at the base of the kerb. The mastic asphalt skirtings are then laid with the top edge turned under the protective hood of the V-Trim.

Priming of the fixing leg is recommended.

