

DADO RAIL

Fixing Instructions

Ensure that the area where installation is to commence is clean and dry. If the area was previously painted, sanding with abrasive paper will improve adhesion.

Measure and cut the Dado Rail using conventional tools such as a general purpose hand saw with a suitably sized mitre block or electric circular saw fitted with a general purpose tungsten tipped blade. When using a circular saw a swift cut generally gives a cleaner edge.

For Dado Rails it is best to mark out the wall using a spirit level and straight edge before commencing installation. The use of small masonry pins nailed along the horizontal pencil lines at suitable centres will help hold the dado rails in position if a no nail adhesive is being used.

After cutting check the dimensions by offering up the cut piece to the fixing position.

Apply the adhesive as per the instructions on the adhesive being used and then install the Dado Rail. Clean off any surplus with a damp sponge and apply filler where necessary.